



- A) Surface Mounted**
1. Remove PC cover + end cap + inner profile
  2. Connect 230V
  3. Fix profile to ceiling using screws  
Only use pre-drilled holes  
Respect screw dimensions
  4. Place PC cover + end cap + inner profile back

**\*NOTE ON USING CONNECTORS (90°/180°)**  
For prevention of light leakage caused by the small gap on the connection of 2 profiles please place tape over gaps. See page "Light leakage prevention"

- C) Wall Mounted**
1. Remove end cap and top cover
  - \*When drilling aid is not supplied:**  
2. Drill holes into profile if they are not pre-drilled  
3. Measure holes (distance A and B)
  4. Drill holes in wall + place plugs or mark screw locations  
Only use countersunk screws, max. screw diameter 5mm
  - \*When drilling aid is supplied:**  
5. Drill holes in wall + place plugs or mark screw locations using aid  
Only use countersunk screws, max. screw diameter 5mm  
Caliper can be fixed into the wall using the 2 positioning slots  
When using positioning slots make sure holes are not visible afterward or can be retouched before placing profile on brackets
  - Further steps:**  
6. Fix wall mounting bracket to wall using screws  
Only use countersunk screws, max. screw diameter 5mm  
7. Place profile on brackets by placing holes over threaded shaft  
8. Fix profile to bracket with toothed lock washer and nut (use wrench)  
9. Place cover and end cap back

**Attention!!**  
Be very careful with LEDs when working on product! Do not touch LEDs  
Do not let tools come in contact with LEDs  
Warranty void if LED contact has taken place  
Only to be installed by a qualified electrician  
Always make sure power is completely switched off when working on profile  
Always make sure suspension cables are placed perpendicular to both the ceiling and the profile itself  
When connecting multiple parts of a structure always make sure LED polarity is respected. This means connecting white to white and grey to grey wires

- 180°+90° Connector**
1. Remove cover and inner profile
  2. Connect power  
Place pieces against each other  
Fix connector bracket using screws (susp. only)
  3. Place covers and inner profile back

- B) Suspended**
1. Disassemble ceiling fixation
  2. Fix ceiling fixation to ceiling using screws
  3. Pull steel wire trough bottom part of ceiling fixation
  4. Reassemble ceiling fixation
  5. Remove end cap
  6. Fix wiregripper onto suspension bracket
  7. Slide suspension brackets into profile  
Move bracket to desired location (>50mm from edge)  
Fix bracket with set screw  
(Bracket cannot be placed above connectors)
  8. Place end cap back
  9. Put wire into wiregripper
  10. Adjust height and cut of excess wire
  11. Place housing over bracket and reassemble  
See page with mounting brackets